

Uberti 1851 Colt Spare Parts List Henry Krank


Individual Spare Parts

Parts 1600-1U - Barrel (Part 1), 1600-14U - Frame (Part 14), and 1600-15U - Cylinder (Part 15) require a variation and can only be ordered over the phone, please contact us on 01132 569163 to order any of the aforementioned parts. For all other parts please order online.

Spare Part Packs

Packs containing a set of spare parts for your gun are available to view and order online at

www.henrykrank.com



Product	Part	Name
1600-1U	Part 1	Barrel
1600-2U	Part 2	Sight
1600-3U	Part 3	Loading Lever Retainer
1600-4U	Part 4	Loading Lever Latch
1600-5U	Part 5	Loading Lever Latch Spring
1600-6U	Part 6	Loading Lever Latch Pin
1600-7U	Part 7	Loading Lever
1600-8U	Part 8	Plunger
1600-9U	Part 9	Plunger Screw
1600-10U	Part 10	Loading Lever Screw
1600-11U	Part 11	Wedge
1600-12U	Part 12	Wedge Screw
1600-13U	Part 13	Base Pin
1600-14U	Part 14	Frame
1600-15U	Part 15	Cylinder
1600-17U	Part 17	Hand and Spring
1600-18U	Part 18	Hammer

Product	Part	Name
1600-19U	Part 19	Hammer Screw
1600-20U	Part 20	Roller
1600-21U	Part 21	Roller Pin
1600-22U	Part 22	Bolt
1600-23U	Part 23	Bolt Screw
1600-24U	Part 24	Trigger
1600-25U	Part 25	Trigger Screw
1600-26U	Part 26	Trigger and Bolt Spring
1600-27U	Part 27	Trigger and Bolt Spring Screw
1600-28U	Part 28	Trigger Guard
1600-29U	Part 29	Rear Trigger Guard Screw
1600-30U	Part 30	Front Trigger Guard Screw
1600-31U	Part 31	Mainspring
1600-32U	Part 32	Mainspring Screw
1600-33U	Part 33	Grips
1600-34U	Part 34	Backstrap
1600-35U	Part 35	Lower Backstrap Screw
1600-36U	Part 36	Rear Backstrap Screw