


# Euroarms Roger & Spencer Spare Parts **Henry Krank**

## Individual Spare Parts

Please note - the only parts we have for the Euroarms Roger and Spencer are listed and can be ordered on the product page (1602E-SPARE), we will not be getting any more stock of any spare parts for this model when stock is depleted.

## Spare Part Packs

Packs containing a set of spare parts for your gun are available to view and order online at [www.henrykrank.com](http://www.henrykrank.com)



Product	Part	Name
1602-1	Part 1	Barrel
1602-2	Part 2	Sight
1602-3	Part 3	Barrel Stud
1602-4	Part 4	Loading Lever Catch
1602-5	Part 5	Loading Lever Spring
1602-6	Part 6	Loading Catch Lever Pin
1602-7	Part 7	Loading Lever
1602-8	Part 8	Cylinder Pin Nut
1602-9	Part 9	Cylinder Pin Nut Screw
1602-10	Part 10	Plunger Screw
1602-11	Part 11	Plunger
1602-12	Part 12	Loading Lever Screw
1602-13	Part 13	Frame
1602-14	Part 14	Cylinder
1602-15	Part 15	Cylinder Pin
1602-16	Part 16	Nipple
1602-17	Part 17	Bolt
1602-18	Part 18	Bolt Screw
1602-19	Part 19	Trigger and Bolt Spring
1602-20	Part 20	Trigger and Bolt Spring Screw
1602-22	Part 22	Trigger
1602-23	Part 23	Grip Frame Screw
1602-24	Part 24	Right Grip

Product	Part	Name
1602-25	Part 25	Right Grip Nut
1602-26	Part 26	Left Grip
1602-27	Part 27	Left Grip Nut
1602-28	Part 28	Grip Screw
1602-29	Part 29	Grip Pin
1602-30	Part 30	Mainspring
1602-31	Part 31	Hammer
1602-32	Part 32	Roller
1602-33	Part 33	Roller Pin
1602-34	Part 34	Hammer Screw
1602-35	Part 35	Hand Assembly
1602-38	Part 38	Sight
1602-40	Part 40	Sight Ramp
1602-41	Part 41	Rear Sight
1602-42	Part 42	Rear Sight Screw
1602-43	Part 43	Rear Sight Blade
1602-44	Part 44	Rear Sight Elevation Screw
1602-45	Part 45	Rear Sight Blade Screw