

LEE DECAPPING DIE

ONE SIZE FITS ALL CASES. CASES NEED NOT BE CLEANED OR LUBED.

Decapper is retained by a collet. Should it be overstressed by an obstruction, it simply slides up without damage. To reset, loosen decapper clamp and position decapper flush with clamp end and tighten. *Considerable torque force may be necessary.*

1/2" and 3/4" wrenches required.

Decapper easily removes crimped-in primers.

Replacement decapper, order #90783



www.leeprecision.com

LD2546

LEE PRECISION, INC.
4275 Hwy. U Hartford Wi 53027

DECAPPING DIE



04.16.13

Lee Precision, Inc.

CHECKED BY

LD2546 Decapping Die 90292