

LEE

LEE PRECISION, INC.

Powder Measure Bottle Adapter


Works on all these and more!

53mm and 43mm threaded bottles



LB4338

① Remove black hopper valve from your powder measure with Phillips screwdriver.



② Attach hopper valve from your powder measure to the bottle adapter, with Phillips screwdriver. Lightly snug screw so that the valve can open & close.



③ Thread on to powder container for use. Rotate clockwise to close the valve, rotate counterclockwise to open valve.

